

"Antikmauer" - Working Instructions

As a general rule, installing the "Antikmauer" requires a simple site preparation, as described below:

Excavate a strip foundation trench approx. 25 cm deep and 40 cm wide. As a next step, apply and compact an approx. 15 cm deep frost protection layer.

The first "Antikmauer" course should later be buried in the earth to around the halfway mark, and is laid level and true onto an approx. 5 cm deep layer of earth-moist concrete, on top of the previously laid frost protection layer.



The following courses are now laid and glued down using an adhesive approved for outdoor use (silicone-free!).



Our tip: It is much easier to fill the cavities in the "Antikmauer" stones with ballast as you complete each course than attempting to do this when your wall is complete!

CHRISTOPH